

CONNECTIONS

Supply voltage must be filtered DC of 10-35V, and ripple should be less than 30% at full load.
CAUTION ! Wrong polarity can damage the unit.
CAUTION ! Unit doesn't have an internal fuse, so an external fuse should be added if fuse required.

FAULT-LED signal codes

- | | |
|---------------------|------------------------------|
| 1. power on | one blink |
| 2. current on limit | led is lit |
| 3. current trip | fast blinking... |
| 4. zero-cur trip | long blink- short pause... |
| 5. overvoltage | 4 x blink -pause... |
| 6. overheat | short blink- long pause... |
| 7. timeout | 3 x blink + long blink... |
| 8. fault input | 2 x short + 1x long blink... |

Limit inputs FW / BW

These inputs stop motor without ramp with dynamic brake
 But in control mode "2-speed" dynamic brake is enabled only when speed-2 is activated.
 If motor has stopped with limit switch the dynamic brake is at least 1s. active, also in case when freewheel is selected.

FAULT in/out

This NPN input pull down when fault. Combination can be selected with parameter 10.
 If this input is pulled down with externally, then it would disabled motor as long as pulled down.

SPEED-2 input

This input activates speed-2 when 2-speed mode is selected
 In analog speed modes this input work as speed set input

SERIAL PORT (red micromatch connector)

This is normally for parameter settings and monitoring with Ementool program or EM-interface units.
 But there is also availability for open protol control (Modbus)
 This option has own instruction guide.


SPECIAL INPUT FUNCTIONS (brackets in drawing)

Analog speed modes sets input as below, mode select with parameter 5

*Analog speed mode-1, pin12= speed set.

*Analog speed mode-2 pin12= speed set, 9=direction, 10=pause

**Analog I-lim input can be enabled with set param. 6&7= 0



SETTINGS and MONITORING (prog ver. EM-241C v1.7)

Settings can be done with three interface device options.

- EM-236 interface unit
- EM-268 interface unit with EmenTool Lite PC-software
- EM-326 interface unit with EmenTool App smartphone application
 When using App you can set device-specific access code, which protects device against unauthorized smartphone connections.
 The access code can be reset with simultaneous FW and BW comand, when power switch on.

SETTABLE PARAMETERS prog. 241C v1.7 (def. in brackets)

- command mode: (0)
 continuous = 0,
 impulse = 1 direction change with stop
 impulse 2 = 2 dir. change without stop
- start condition combinations: 0-3 (1)
 0= start both direction after I-trip and Stop
 1= start only opposite direction after I-trip
 2= start only opposite direction after Stop
 3= start only opposite direction after I- and Stop
- input logic combinations 0-7 PNP/NPN (0)
 PNP control with positive signal and input has pull down res.
 NPN control with negative signal and input has pull up res.
 N.C. = input resistor as above, but control signal logic is inverted
 0= cont. PNP, limits PNP 4=cont. PNP, limits PNP N.C.
 1= cont. NPN, limits PNP 5=cont. NPN, limits PNP N.C.
 2= cont. PNP, limits NPN N.C. 6=cont. PNP, limits NPN
 3= cont. NPN, limits NPN N.C. 7=cont. NPN, limits NPN
- running speed-1: 0-100% / 0-100 (100)
 If analog speed input mode is select with parameter 5,
 then parameter 4 work analog input range adjust
 *5 control mode / running speed-2 preset 0-100% / 0-100 (50)
 0= Analog speed mode -1
 "speed 2-input" is used as analog 0-5V speed control input.
 1= Analog speed mode -2
 as above but FW direction is automatically "on" and
 FW input works as direction change input.
 BW input works as pause input
 2-100 = 2-speed mode (two digitally settable speed)
 speed-1 preset with param. 4 and speed-2 with param. 5)
 **6 current limit FW: 0.1-25A / 1-250 (30)
 **7 current limit REV: 0.1-25A / 1-250 (30)
 NOTICE ! If both 6 & 7 is set = 0, then I-limit input is enabled,
 and works as current limit adjust input.
- Trip combinations: 0-3 (1)
 0= no I-trip, no zero-current-trip
 1= only I-trip
 2= only zero-current-trip
 3= both I-trip and zero-current-trip
- I-trip delay: 0-255ms / 0-255 (20)
- Fault output combinations: 0-3 (1)
 0= I-trip and zero current won't cause fault output signal
 1= only I-trip causes fault output signal
 2= only zero current causes fault output signal
 3= both I-trip and zero current causes fault output signal.
 4= overcurrent indication = pull down
 5= "run" indication = pull down when motor run
- overvoltage limit: 15-60V / 15-60 (55)
 Overvoltage can be caused by load driving the motor or
 when braking the speed down but supply can not accept
 the current back from driver. Exceeding the limit will cause
 the power stage set to free-wheel state.
 With a direct battery supply the brake current is charging the
 battery and the voltage will not normally rise.
- load compensation: 0-255 / 0-255 (0)
 Load compensation (Rxl) improves low speed and start
 torque, but too high compensation achieve unstable running.
 Run motor at low speed (30%) Increase compensation
 with small steps until motor start behaviour unstable,
 then decrease value about 10%
- timeout: 0-255s. / 0-255 (0=not in use) (0)
- reset for start and hour-counter 0/1 (0)
 selecting 1 and push save = reset counters
- start ramp: 0-5s / 0-500 (100)
- stop ramp: 0-5s / 0-500 (100)
- start kick 0-200ms / 0-200 (0)
 gives short 0-200ms full drive pulse for start
- I-trip auto reversing 0-5s / 0-500 (0)
 Change automatically run direction when I-trip occurs
 the revesing time will select with this parameter
- Freewheel options 0-3 (0)
 0= freewheeling when overvoltage
 1= freewheeling when overv. or stopped
 2= freewheeling when overv. or during stop ramp
 3= freewheeling when overv. or when stopped or during stop ramp
- Pwm frequency 1=2kHz / 2=16kHz (1)
- Serial port configuration, speed, parity, and number of stop bits (1)
 1 =9600bps 8N1 5 =19200bps 8N1
 2 =9600bps 8N2 6 =19200bps 8N2
 3 =9600bps 8E1 7 =19200bps 8E1
 4 =9600bps 8O1 8 =19200bps 8O1
- Modbus address 1-247 (1)

MONITORABLE VALUES

- Motor current 0-2.0A (0-200)
- PWM-level-% 0-100% (0-100)
- hour counter (max.65535h)
- start counter (max.65535)
- carry counter for start counter